

品番

MS-X201B

お客様へ

ご使用の前にこの取扱説明書をよくお読みのうえ、正しく安全にお使いください。
この説明書は、大切に保管してください。

安全上のご注意



警告

この表示は、誤った取り扱いをすると死亡または重傷を負う可能性が想定される内容を示します。

- ハニカムルーバーの取り付けは、取扱説明書に従い確実に行ってください。
- 本ハニカムルーバーはSALIOT専用のオプション部品です。
指定以外の器具で使用すると、器具破損・落下の原因となります。
- 取り付け作業の際は必ず電源を切ってください。感電の原因となります。
- 布や紙などで覆って使用しないでください。火災の原因となります。



注意

この表示は、傷害を負うことや、財産の損害が発生する可能性が想定される内容を示します。

- ハニカムルーバーを取り付ける際に器具に無理な力を加えないでください。落下の原因となります。
- 取り付け時に不備があると落下のおそれがあります。
- ルーバー部に強い力を加えると変形を起こし、機能の低下や異常な発熱をまねく恐れがあります。
- 点灯中および消灯直後は器具が高温になっていますので、触らないでください。やけどの原因となります。
- お手入れの際は、必ず電源を切って行ってください。感電・やけどの原因となります。
- ハニカムルーバーを取り付けた場合、埃などが溜まりやすくなるため、定期的に清掃をしてください。

各部の名称と取付方法


取り付け方

- ① ハニカムルーバーの引掛け爪(3箇所)がある方を、灯具の照射部側に向ける。
- ② ハニカムルーバーを押し込む。押し込むと照射部の溝に、引掛け爪(3箇所)が引っ掛かる。



取り付け時に不備があると落下の原因となります。


ハニカムルーバーを取り付ける際、ルーバー部を持つと変形や破損のおそれがあります。



取り外し方

- ① ハニカムルーバーの取り外し用の穴(3箇所)に嵌る工具を準備する。
(推奨工具: 小型マイナスドライバー 4.5×50)
- ② 取り外し用の穴に工具を差し込み、少し持ち上げて、引掛け爪を照射部の溝から取り外す。
それを順次に3箇所行い、ハニカムルーバーを取り外す。

⚠ ハニカムルーバーを取り外す際、ルーバー部を持つと変形や破損のおそれがあります。



お手入れ



⚠ 器具のお手入れの際は、必ず電源を切ってください。感電・やけどの原因となります。

- ハニカムルーバーの汚れは乾いた柔らかい布で埃を拭き取る、但し、ルーバー部分に強い力を加えないで下さい。変形の恐れがあります。
- シンナーやベンジンなどの揮発性のもので拭いたり、殺虫剤をかけたりしないでください。
変色・変質・故障の原因になります。

保証について

- この商品の保証期間はご購入時より1年間です。
- 保証書が必要な場合は、お問い合わせ先へご連絡ください。

適用器具について

品番	適用器具	
MS-X201B	MS-S6 シリーズ	MS-D6 シリーズ
		
詳細なモデル型番は、下記お問い合わせ先にお問い合わせください。		

お問い合わせ先

TEL : 03-6758-6711


受付時間：月～金 / 9:00～17:00 (土・日曜・祝日・年末年始・当社休業日を除く)

ミネベアミツミ株式会社 東京本部 スマート製品事業部
〒105-0021 東京都港区東新橋1丁目9番3号

Part No.	MS-X201B
----------	----------


To The Customer Read this Instruction Manual thoroughly before you use the product to ensure correct and safe use. Store this Instruction Manual in a safe place.

Safety Precautions

**WARNING**

This symbol indicates that there is the risk of death or serious injury if the product is improperly handled.

- Be sure to install the HONEYCOMB LOUVER securely by following the Instruction Manual.
- This HONEYCOMB LOUVER is an optional part exclusively for SALIOT.
Using this product with other than the specified lighting fixture may result in fire, electric shock, or falling.
- Be sure to turn the power OFF when installing. Failure to heed this caution may result in electric shock.
- Do not cover the lighting fixture with cloth, paper or other materials during use.
Failure to heed this warning may result in fire.

**CAUTION**


This symbol indicates that there is the risk of injury or damage to property.

- Do not apply unreasonable force to the lighting fixture when installing the HONEYCOMB LOUVER.
Failure to heed this caution may result in falling.
- Defective installation may result in falling.
- Do not apply strong force to the louver part. It may cause deformation and may lead to deterioration of function or abnormal heat generation.
- Do not touch the lighting fixture immediately after turning off and while light is on as it is very hot.
Failure to heed this caution may result in burns.
- Be sure to turn the power OFF before performing daily care or maintenance.
Failure to heed this caution may result in electric shock or burns.
- In case of installing the HONEYCOMB LOUVER, dust and others will be easy to accumulate, so clean it periodically.

Name of Parts and Installation Procedure

Installation Procedure


- ① Face the side of the HONEYCOMB LOUVER with hooking claws (3 places) toward the irradiation part of the lighting fixture.
- ② Push in the HONEYCOMB LOUVER. When pushed in, hooking claws (3 places) are caught in the groove of the irradiation part.



Defective installation may result in falling.

Do not hold the louver part when installing the HONEYCOMB LOUVER.


Doing do may result in deformation or damage.




Removal Procedure

- ① Prepare a tool that fits into the holes (3 places) for removing the HONEYCOMB LOUVER.
(Recommended tool: Small slotted head screwdriver 4.5 times 50)
- ② Insert the tool into the holes for removal and lift it slightly to remove the hooking claws from the groove of the irradiation part. Do this in 3 places, and remove the HONEYCOMB LOUVER.

 **Do not hold the louver part when installing the HONEYCOMB LOUVER.**
Doing so may result in deformation or damage.



Maintenance



 **Be sure to turn the power OFF before performing daily care or maintenance.**
Failure to heed this warning may result in electric shock or burns.

- Wipe dust off the HONEYCOMB LOUVER with a dry soft cloth, however do not apply strong force to the louver part. It may result in deformation.
- Do not wipe with volatile solvents such as thinner or benzene and do not spray pesticide.
Doing so may cause discoloration, degeneration or malfunction.

Guarantee

- This product is guaranteed for one year from the date of purchase.
- If a Warranty is required, contact the contact information below.

Applicable Lighting Fixture

Part / No.	Applicable Lighting Fixture	
MS-X201B	MS-S6 series	MS-D6 series
		
For detailed model number, please contact the following contact information.		

Contact Information

TEL : +81-3-6758-6711
Reception time : From Monday through Friday / 9:00 to 17:00
(Sat., Sun., public holiday, New year's holiday and our company holiday exclude.)
MinebeaMitsumi Inc. Tokyo Head Office, Smart Products BU
1-9-3 Higashi-Shinbashi, Minato-ku, Tokyo 105-0021